

## Application of Overlaminates

Always chose a compatible or matched overlaminate to ensure mutual weathering and to avoid tunnelling or delaminating. Allow sufficient time (24-48 hours) for the print to fully cure before attempting to overlaminate, and ensure that the media and overlaminate are at room temperature.

For best results use a laminating machine. Metamark Overlaminates are suitable for cold lamination, though it is recommended to apply nominal heat (30'C) to the top roller to minimise 'silvering'. All Metamark overlaminates have a solvent-based adhesive\* to ensure trouble free application whether applying wet or dry.

To avoid tunnelling and delamination, roll the materials 'Print side out' and avoid rolling tightly.

## \*Except MetaGuard MG-100

## For further technical support email technical@metamark.co.uk or call +44 (0)1483 571111

**Metamark (UK) Limited** Luneside • New Quay Road • Lancaster • LA1 5QP • Tel +44 (0)1524 387140 • Fax +44 (0)1524 387147 Metamark House • Octimum Business Park • Forsyth Road • Woking • GU21 5SF • Tel +44 (0)1483 571111 • Fax +44 (0)1483 570540

sales@metamark.co.uk www.metamark.co.uk